


Indicators & Display

Hourmeter

When selected, the hourmeter (1) shows accumulated hours while the ignition is ON (1). The hourmeter provides accurate service period information for initial and regular maintenance. To change the display from the digital clock to the hourmeter, press and release the hourmeter/digital clock select button (3). The hourmeter mark (2) will appear.



(1) hourmeter
(2) hourmeter mark

(3) hourmeter/digital clock
select button