

# MAINTENANCE

## MAINTENANCE SCHEDULE

- The maintenance intervals shown in the following schedule are based upon average riding conditions. FOUR TRAX's subjected to severe use, or ridden in unusually dusty areas, require more frequent servicing. Perform the Pre-ride Inspection (page 28) at each scheduled maintenance period.

I: Inspect and Clean, Adjust, Lubricate or Replace, if necessary C: Clean      R: Replace A: Adjust      L: Lubricate		INITIAL SERVICE PERIOD (First week of operation)	REGULAR SERVICE PERIOD (Every 30 operating days)	Refer to page
*	FUEL LINE	YEAR I		45
*	FUEL STRAINER SCREEN	YEAR C		45
*	THROTTLE OPERATION		I	I
	AIR CLEANER	NOTE 1		C
	SPARK PLUG			I
*	VALVE CLEARANCE		I	I
	ENGINE OIL		R	R
**	ENGINE OIL STRAINER SCREEN			C
**	ENGINE OIL CENTRIFUGE FILTER			C
*	CARBURETOR IDLE SPEED		I	I
	DRIVE CHAIN	NOTE 1	I, L	I, L
	DRIVE CHAIN SLIDER			I
				—