


TOOL KIT

The tool kit (1) is in the tool box (2) on the lower left side of the seat.

Insert the ignition key (3), turn it clockwise to unlock and open the tool box.

Some roadside repairs, minor adjustments and parts replacement can be performed with the tools contained in the kit.

- 10 × 12 mm open end wrench
- 10 × 14 mm open end wrench
- 8 mm open end wrench
- 6 mm hex wrench
- Pliers
- No. 2 Phillips screwdriver
- No. 3 Phillips screwdriver
- Screwdriver handle
- 17 mm box end wrench
- 24 mm box end wrench
- Extension bar
- Spark plug wrench
- Fuse remover
- Tool bag



- (1) Tool kit
(2) Tool box

- (3) Ignition key