


Instruments *(Continued)*

To reset the tripmeter, average fuel mileage, fuel consumption, average speed and elapsed time

To reset tripmeter A, average fuel mileage, fuel consumption, average speed and elapsed time (these are based on tripmeter A) together, press and hold the **MODE** button while tripmeter A or odometer and average fuel mileage, fuel consumption, average speed and elapsed time is displayed.



Then, the display returns to the last selected indication.

Also, the tripmeter A, average fuel mileage, fuel consumption, average speed and elapsed time will automatically reset by refueling more than the reserve amount and riding your motorcycle for 0.06 mile (0.1 km). You can activate or deactivate the automatic reset mode by refueling. ➔ **P.37**