

Inspecting the Brake Pads

Check the condition of the brake pad wear indicators.

The pads need to be replaced if a brake pad is worn to the indicator.

- Front** Inspect the brake pads from below the brake caliper.
- Rear** Inspect the brake pads from the rear right of the vehicle.

