


## Brightness

You can select the backlight brightness.

The display can become dark when the display is very hot. If it does not restore the original brightness, contact your dealer.

### Automatic Brightness Control: P.324



1 Select [Brightness], and then press the **ENT** switch.

2 Select [Auto], and then press the **ENT** switch to [ON] (auto) or [OFF] (manual) the function.

