

Function lever



- Push forward or pull backward to adjust the audio system volume. **▶P.150**
- Push forward or pull backward to adjust the grip heater level. **▶P.127**



Voice control switch / Page switch

- Push forward to receive, reject or end a call. **▶P.183**
- Push forward to start Siri if Apple CarPlay is available. **▶P.198**
- Pull backward and hold to go to the Home screen or Apple CarPlay screen. **▶P.36**
- Pull backward to return to the riding information or audio screen. **▶P.38**

Headlight dimmer/Passing

light control switch

- : High beam
- : Low beam
- : Flashes the high beam headlight.

Shift up switch (+)

CRF1100D/D4

To shift up the gear. **▶P.209**

