


Selecting the riding mode

When change the riding mode, the rear wheel ABS function [ABS RR] will automatically be set to [ACTIVE].

- When using the  sel up switch and  sel down switch:

- 1 Press the  sel up switch or  sel down switch.



You can also perform the above settings by using the touch screen.

- When using the  favorite switch:
 - 1 Select the [Riding Mode] of the  favorite switch. 
 - 2 Press the  favorite switch.