

Adjusting the Brake Light Switch

Check the operation of the brake light switch.
Hold the brake light switch and turn the adjusting nut in the direction A if the switch operates too late, or turn the nut in the direction B if the switch operates too soon.

