

Symptom	Cause/remedy
Sounds skip Noises mix	Depending on the <i>Bluetooth</i>® device and application software you use, an audio file may not play normally after receiving a telephone call, etc. Turn off the power to the audio system and then turn it on again. If the skipping of sounds or mixing of noises continues, check the status of your <i>Bluetooth</i>® device. If the skipping of sounds or mixing of noises continues, delete the paired device once, then try pairing again. ➔ P. 162 Check the recommended specifications. ➔ P. 153