

Symptom	Cause/remedy
Audio volume from headset is low/high.	<p>Adjust the volume while in the individual modes. ➔ P. 91</p> <p>Check the volume setting of the <i>Bluetooth</i>® audio device.</p> <p>Check the volume setting of the paired headset.</p>
No or inaccurate display	<p>Depending on the audio device and the audio file, nothing may be displayed or the display may be inaccurate in some cases.</p> <p>Check the information on available tags. ➔ P. 171</p> <p>When the information in an audio file such as the artist name and track title is in a non-compliant tag format, it may be indicated by "☒" or no information will be shown.</p>