

Symptom	Cause/remedy
Bluetooth® handsfree calling cannot be available.	Connected <i>Bluetooth</i>® device may be an unsupported device. Check the supported <i>Bluetooth</i>® version/profiles. ➔ P. 153 When the <i>Bluetooth</i>® connection is unstable due to surrounding conditions or radio wave conditions, the handsfree calling functions may not be available. To use <i>Bluetooth</i>® handsfree calling, a headset connection is necessary. Connect a paired headset. ➔ P. 159
During a call, headset volume is low/high.	Adjust the volume during a call. ➔ P. 91
Passenger's headset is no sound	Passenger headset only outputs music. Music playback is interrupted while using the handsfree phone or Siri.