

Switches

Ignition switch

Switches the electrical system on/off, locks the steering.


- ▶ Key can be removed when in the OFF or  (LOCK) position.



Start button



Horn button



Turn signal switch

- ▶ Pressing the switch turns the turn signal off.

Headlight dimmer switch

- : High beam
- : Low beam

