

Final Drive Oil

5. Pour the drained oil into a suitable container and dispose of it in an approved manner (page 149).

NOTICE

Improper disposal of drained fluids is harmful to the environment.

6. Fill the final drive with the recommended oil:

5.4 US oz (160 cm³)

Make sure the final drive oil level is at the lower edge of the oil fill hole (4).

7. Install the oil fill cap and tighten to the specified torque:

9 lbf·ft (12 N·m , 1.2 kgf·m)