Switches



Engine stop switch
Should normally remain in the RUN position.
u In an emergency, switch to the OFF position to stop the engine.

Start button
Headlight turns off when operating the starter motor.

Horn button

Turn signal switch

Headlight dimmer switch
- : High beam
- : Low beam